

# SIL SG102-10 Service Information Letter SG102 AHRS

Date: October 15, 2014

Regarding: SG102 AHRS Software Release 1.61

SIL Revision: A (Initial)

#### Reason

This Service Information Letter is informational only. No action is required.

An issue affecting SG102 internal calibration during the production process was reported. Units presently in service are not affected.

# **Applicability**

Sandel Model SG102 - part number SG102-X00 with MOD 2 Sandel Model SG102/D - part number SG102-X50

# **Description**

SG102 software was revised to version 1.61 for improved manufacturing yield and incorporated into current production. Pilot operation is unchanged.

<u>Field calibration:</u> SG102 field calibration software has been updated to version 2.80. This version or later is required for calibrating new installations with SG102 software version 1.61.

<u>Note regarding spares:</u> SG102 software version 1.61 is backward compatible with prior field calibrations in existing installations with SG102 software version 1.26 or later.

### Compliance

Not required for existing installations. Software version 1.61 is not field loadable.

# Warranty Reimbursement

N/A

#### Manpower

N/A

#### Approval

This modification does not affect the original approval.



# Identification

No change

# **Testing**

None

#### **Related Documentation**

82011-IM Rev. J (or later)

82011-PGERR Rev. E2

82011-ICUG Rev. G

Installation Manual (No content changed)

Pilots Guide Errata (No content changed)

Installation/Calibration Utility User Guide

**END**